

Abnormal Test

Manufacturer : COSEL CO., LTD.

Tested Model [機種名] : YS1012U/Y S1012A

Input Ratings [入力定格] :

Voltage AC 100-120 V

Frequency 50-60 Hz

Current	0.3	A
---------	-----	---

Output Ratings [出力定格]:

Voltage	12	V	Current	0.9	A
---------	----	---	---------	-----	---

_____ V _____ A

_____ V _____ A

_____ V _____ A

V A

V A

Conducted by [試験担当] : S. Orita

Reviewed by [照査] : Y. Tanno

Abnormal Test [アブノーマル試験]

Rated Input Current: 0.3 A, Rated Output Voltage: 12 V

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
1	C1	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
2		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
3	C2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
4		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
5	C3	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
6		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
7	C4	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R1, R2 Opened
8		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
9	C5	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
10		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
11	C6	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
12		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または熔融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
13	C7	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
14		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
15	C8	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
16		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
17	C10	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
18		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
19	C11	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
20		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.01	12V →0.5V	
21	C12	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
22		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
23	C13	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.01	12V →0V	
24		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
25	C14	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.01	12V →0V	
26		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
27	C15	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.01	12V →0V	
28		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
29	C17	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
30		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
31	C18	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
32		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
33	C19	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.05	12V →0V	
34		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
35	C20	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	12V →11V	
36		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
37	C21	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
38		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
39	C26	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
40		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
41	D1	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
42		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
43	D2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
44		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
45	D3	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
46		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
47	D4	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
48		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Current	Output Voltage	Comment [コメント]
49	D5	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
50		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
51	D6	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.001	Shut Down	
52		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
53	D8	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.04	12V →3.8V	
54		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.02	12V →2.6V	
55	IC1	A-R S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.25	12V →14V	
56		A-K S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.01	12V →4V	
57		R-K S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.02	12V → 8V	
58		R OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.25	12V→ 14.5V	
59		A OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.25	12V→ 14.5V	
60		K OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.25	12V→ 14.5V	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
61	L1	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
62		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
63	L2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
64		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
65	PC1	C-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.01	12V →2V	
66		C, E OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
67		A-K S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
68		A, K OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
69	R1	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
70	R2	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
71	R3	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
72	R4	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
73	R5	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
74	R6	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
75	R9	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
76	R10	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
77	R11	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
78	R12	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
79	R14	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
80	R15	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
81	R16	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
82	R17	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
83	R18	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
84	R19	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または熔融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
85	R25	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.02	12V →2.7V	
86	R26	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
87	R27	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
88	R28	OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
89	SS1	+ OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
90		- OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
91		~ OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
92		+++ S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
93		+-~ S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
94		--- S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R1, R2 Opened
95	SS2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18, R19 Opened
96		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
97	SS3	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
98		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None Down	
99	T1	4-5 S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
100		4,5 OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input type="checkbox"/> No [無]	0	Shut Down	
101		1-2 S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
102		1.2 OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
103		2-3 S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
104		2,3 OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
105		8.9-6.7 S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
106		8.9,6.7 OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
107	TR1	E OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
108		B OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
109	TR1	C OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
110		C-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
111		C-B S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
112		B-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
113	TR2	E OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
114		B OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
115		C OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
116		C-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
117		C-B S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
118		B-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
119	TR3	E OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
120		B OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	

No.	Component [部品番号]	S/C[短絡] or OPEN [開放]	Gnd Fuse Open [接地ヒューズ断]	Flame or Glowing [赤熱または溶融]	Input Curr- ent	Output Volta- ge	Comment [コメント]
121	TR3	C OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
122		C-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	R18,R19 Opened
123		C-B S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	TR3 Shorted R18,R19 Opened
124		B-E S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0	Shut Down	
125	ZD1	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.06	12V →5.2V	
126		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
127	ZD2	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	0.03	12V →4V	
128		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
129	ZD4	S/C	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
130		OPEN	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	None	None	
131			<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]			
132			<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]	<input type="checkbox"/> Yes[有] <input checked="" type="checkbox"/> No [無]			

Compliance [判定] : ☒ Yes [合] / ☐ No [否]